

Ruurlo, July 2023

PRESS RELEASE

Compact Heavy-Duty Coriolis Flow Meter

FOR LOW FLOW RATES

Bronkhorst High-Tech, specialist in low flow measurement and control technology, presents a new, compact, and robust Coriolis mass flow meter. The mini CORI-FLOW MI100 series integrates an innovative flow sensor and electronics into a weatherproof housing, equipped with cable glands and screw terminals, suitable for industrial applications.

This reliable meter utilizes integrated optical sensor technology, ensuring highly precise measurement of extremely low gas and liquid flows, ranging from 1 g/h to 30 kg/h. As a standard feature, the flow meter includes an integrated PID controller, allowing for the creation of a compact flow control system when combined with a close-coupled pump or valve. The instrument also offers additional functionalities, such as alarms and counters, and boasts extensive connectivity options supporting RS232/RS485, Industrial Ethernet, or analog I/O for seamless integration into any system.

For more information visit www.bronkhorst.com or contact us at info@bronkhorst.com



mini CORI-FLOW™ Coriolis Flow Meter for low flow rates

LOW FLOW FLUIDICS HANDLING TECHNOLOGY

Bronkhorst High-Tech B.V. Nijverheidsstraat 1a NL-7261 AK Ruurlo, The Netherlands

+31 573 45 88 00 info@bronkhorst.com www.bronkhorst.com Bank ABN-AMRO Utrecht IBAN NL84 ABNA 0434 3525 35 BIC ABNANL2A VAT NL801989978B01 Chamber of Commerce Arnhem 08058979

